

# Asphalt Under-Coating

## Application Note

### Significant Issue:

Asphalt undercoatings use Interfibe to maintain sag Resistance so the coating can be applied without dripping.

### Customer Objectives:

As a safe alternative, Interfibe fibers are used too control reology, film thickness, and internal reinforcement in under-coating formulations. Specific products are compatible with conventional spray nozzle sizes.

### Interfibe Solution:

Interfibe Gel-Cel 10 will provide excellent suspension properties and non-drip performance when used at 4% by weight. Formulations containing Gel-Cel 10 can be sprayed through conventional spray nozzles without clogging and will maintain a uniform fiber structure in the cured undercoating.

***interfibe***<sup>™</sup>

*For further information, call  
your local distributor or  
Interfibe Corporation.*

Interfibe is a trademark of Interfibe Corporation  
©1996 Interfibe Corporation

**Phone: (800) 262-3771  
Fax: (216) 248-2132**

# Asphalt Under-Coating

## Application Note

### FIBRATED AEROSOL UNDERCOATING\*

#### FORMULATIONS (WT. %)

<b>Order of Addition</b>	
Grade A Cut- Back Asphalt	82.0%
Surfactant	2.0%
<i>Mix 5 Minutes</i>	
Attapulgate Clay	12.0%
<i>Mix Minimum 10 Minutes</i>	
Interfibe Gel-Cel 10	4.0%
<i>Mix Minimum 10 Minutes</i>	
Clay/Surfactant Ratio	6:1
<b>TOTAL MINERAL (wt. %)</b>	<b>16%</b>

\*Formulated to Meet: Federal Specifications SS-A-694D  
ASTM Specification D-2823

The data included represent typical product characteristics. We cannot anticipate all conditions under which this information and our products, or the products of other manufacturers in combination with our products, may be used. We accept no responsibility for results obtained by the application of this information or the safety and suitability of our products, either alone or in combination with other products. Users are advised to make their own tests to determine the safety and suitability of each such product or product combination for their own purposes. Unless otherwise agreed to in writing, we sell the products without warranty, and buyers and users assume all responsibility and liability for loss or damage arising from the handling and use of our products, whether used alone or in combination with other products.

***interfibe***<sup>TM</sup>

*For further information, call  
your local distributor or  
Interfibe Corporation.*

**Phone: (800) 262-3771  
Fax: (216) 248-2132**